


## SERVICE MANUAL

## FE-1 CHASSIS

<i>MODEL</i>	<i>COMMANDER</i>	<i>DEST</i>	<i>CHASSIS NO.</i>	<i>MODEL</i>	<i>COMMANDER</i>	<i>DEST</i>	<i>CHASSIS NO.</i>
<b>KV-21M5D</b>	RM-883	AEP	SCC-Q04M-A	<b>KV-21T5K</b>	RM-883	OIRT	SCC-Q03X-A
<b>KV-21T5D</b>	RM-883	AEP	SCC-Q04N-A	<b>KV-21T5R</b>	RM-883	OIRT	SCC-Q03W-A
<b>KV-21M5K</b>	RM-883	OIRT	SCC-Q03V-A				



TRINITRON® COLOR TV  
**SONY®**




ITEM MODEL	Television System	Channel Coverage	Color System
AEP	B/G/H	VHF : E2-E12, A-H2, R01-R12 UHF : E21-E69, B21-B69, R21-R69 CABLE TV : S01-S05, S1-S20 HYPER : S21-S41	PAL, SECAM
OIRT	B/G/H, D/K	VHF : E2-E12, R01-R12 UHF : E21-E69, R21-R60 CABLE TV : S01-S03, S1-S20 HYPER : S21-S41	PAL, SECAM NTS04.43, NTSC3.58 (VIDEO IN)

MODEL	21M5D 21T5D	21M5K 21T5K	21T5R
Power Consumption	60W	60W	60W

**[PICTURE TUBE]** Super Trinitron  
Approx. 55cm (21 inches)  
(Approx. 51cm picture measured diagonally)  
110 degree deflection



#### Input/Output Terminals

#### [REAR]

 21-pin Euro connector (CENELEC standard).

- Inputs for Audio and Video signals.
- Inputs for RGB.
- Outputs of TV Video and Audio signals.

#### [FRONT]

-  2 Video input - phono jack
-  Audio inputs - phono jacks
- Headphone jacks : minijack



Sound output 2 x 4.5W (Music Power)  
Power requirements 220 - 240V  
Dimensions Approx 598x456x467mm  
Weight Approx 21kg  
Supplied accessories RM-883 Remote Commander (1)  
IEC designated R6 battery (2)  
Other features TELETEXT (For KV-21T5 models)

#### [RM-883]


Remote control system Infrared control  
Power requirements 1.5V dc  
2 batteries IEC designation  
R6 (size AA)  
Dimensions Approx 65x225x21mm (w/h/d)  
Weight Approx 157g (Not including battery)

**Design and specifications are subject to change without notice.**

Model Name	KV-21M5D	KV-21M5K	
Item	KV-21T5D	KV-21T5K	KV-21T5R
Pal Comb	OFF	OFF	OFF
PIP	OFF	OFF	OFF
Woofers Box	OFF	OFF	OFF
Scart 1	ON	ON	ON
Scart 2	OFF	OFF	OFF
Front in (3)	ON	ON	ON
Scart 4	OFF	OFF	OFF
Projector	OFF	OFF	OFF
AKB in 16:9 mode	ON	ON	ON
Norm B/G	ON	ON	ON
Norm I	OFF	OFF	OFF
Norm D/K	OFF	ON	ON
Norm AUS	OFF	OFF	OFF
Norm L	OFF	ON	OFF
Norm SAT	OFF	OFF	OFF
Norm M	OFF	OFF	OFF
Language Preset	German	OIRT	OIRT



Pin No	1	2	4	Signal	Signal level
1	○	○	○	Audio output B (right)	Standard level : 0.5V rms Output impedance : Less than 1kohm*
2	○	○	○	Audio output B (right)	Standard level : 0.5V rms Output impedance : More than 10kohm*
3	○	○	○	Audio output A (left)	Standard level : 0.5V rms Output impedance : Less than 1kohm*
4	○	○	○	Ground (audio)	
5	○	○	○	Ground (blue)	
6	○	○	○	Audio input A (left)	Standard level : 0.5V rms Output impedance : More than 10kohm*
7	○	●	●	Blue input	0.7 +/- 3dB, 75 ohms positive
8	○	○	○	Function select (AV control)	High state (9.5-12V) : Part mode Low state (0-2V) : TV mode Input impedance : More than 10K ohms Input capacitance : Less than 2nF
9	○	○	○	Ground (green)	
10	○	○	○	Open	
11	○	●	●	Green	Green signal : 0.7 +/- 3dB, 75 ohms, positive
12	○	○	○	Open	
13	○	○	○	Ground (red)	
14	○	○	○	Ground (blanking)	
15	○	-	-	Red input	0.7 +/- 3dB, 75 ohms, positive
	-	○	○	(S signal Chroma input)	0.3 +/- 3dB, 75 ohms, positive
16	○	●	●	Blanking input (Ys signal)	High state (1-3V) Low state (0-0.4V) Input impedance : 75 ohms
17	○	○	○	Ground (video output)	
18	○	○	○	Ground (video input)	
19	○	○	○	Video output	1V +/- 3dB, 75ohms, positive sync 0.3V (-3+10dB)
20	○	-	-	Video input	1V +/- 3dB, 75ohms, positive sync 0.3V (-3+10dB)
	-	○	○	Video input Y (S signal)	1V +/- 3dB, 75ohms, positive sync 0.3V (-3+10dB)
21	○	○	○	Common ground (plug, shield)	



# TABLE OF CONTENTS

Section	Title	Page	Section	Title	Page
<b>1. GENERAL</b>			<b>5. DIAGRAMS</b>		
	Overview of TV buttons	6	5-1.	Block Diagrams	23
	Using Select Mode	6	5-2.	Circuit Board Location	27
	Adjusting the Picture	7	5-3.	Schematic Diagrams and Printed Wiring Boards	27
	Using the Sleep Timer	7		* A Board	31
	Using the Wake Up Timer	8		* C Board	36
	Viewing Teletext	8	5-4.	Semiconductors	39
	Exchanging Programme Pos	9	5-5.	IC Blocks	40
	Manually Tuning the TV	9			
	Fine-Tuning Channels	10	<b>6. EXPLODED VIEWS</b>		
	Skipping Programme Pos	10			
	Using Optional Equipment	11	6-1.	Chassis	41
	Troubleshooting	11	6-2.	Picture Tube	42
<b>2. DISASSEMBLY</b>			<b>7. ELECTRICAL PARTS LIST</b>		43
	2-1. Rear Cover Removal	12			
	2-2. Chassis Assy Removal	12			
	2-3. Service Position	12			
	2-4. Picture Tube Removal	13			
<b>3. SET-UP ADJUSTMENTS</b>					
	3-1. Beam Landing	14			
	3-2. Convergence	15			
	3-3. Screen [G2] White Balance	17			
	3-4. Focus	17			
<b>4. CIRCUIT ADJUSTMENTS</b>					
	4-1. Electrical Adjustments	18			
	4-2. Test Mode 2	21			
	4-3. FE-1 Self Diagnostic Software	22			


## CAUTION

**SHORT CIRCUIT THE ANODE OF THE PICTURE TUBE AND THE ANODE CAP TO THE METAL CHASSIS, CRT SHIELD, OR THE CARBON PAINTED ON THE CRT, AFTER REMOVAL OF THE ANODE CAP**

## WARNING !!

AN ISOLATING TRANSFORMER SHOULD BE USED DURING ANY SERVICE WORK TO AVOID POSSIBLE SHOCK HAZARD DUE TO LIVE CHASSIS. THE CHASSIS OF THIS RECEIVER IS DIRECTLY CONNECTED TO THE POWER LINE.

## SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY SHADING AND MARKED  ON THE SCHEMATIC DIAGRAMS, EXPLODED VIEWS AND IN THE PARTS LIST ARE CRITICAL FOR SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.


## ATTENTION

**APRES AVOIR DECONNECTE LE CAP DE L'ANODE, COURT-CIRCUITER L'ANODE DU TUBE CATHODIQUE ET CELUI DE L'ANODE DU CAP AU CHASSIS METALLIQUE DE L'APPAREIL, OU AU COUCHE DE CARBONE PEINTE SUR LE TUBE CATHODIQUE OU AU BLINDAGE DU TUBE CATHODIQUE.**

## ATTENTION !!

AFIN D'EVITER TOUT RISQUE D'ELECTROCUTION PROVENANT D'UN CHÂSSIS SOUS TENSION, UN TRANSFORMATEUR D'ISOLEMENT DOIT ETRE UTILISÉ LORS DE TOUT DÉPANNAGE. LE CHÂSSIS DE CE RÉCEPTEUR EST DIRECTMENT RACCORDÉ À L'ALIMENTATION SECTEUR.

## ATTENTION AUX COMPOSANTS RELATIFS À LA SÉCURITÉ !!


LES COMPOSANTS IDENTIFIÉS PAR UNE TRAME ET PAR UNE MARQUE  SUR LES SCHÉMAS DE PRINCIPE, LES VUES EXPLOSÉES ET LES LISTES DE PIÈCES SONT D'UNE IMPORTANCE CRITIQUE POUR LA SÈCURITÉ DU FONCTIONNEMENT, NE LES REMPLACER QUE PAR DES COMPSANTS SONY DONT LE NUMÈRE DE PIÈCE EST INDIQUÉ DANS LE PRÈSENT MANUEL OU DANS DES SUPPLÈMENTS PUBLIÈS PAR SONY.

## SECTION 1 GENERAL


The operating instructions mentioned here are partial abstracts from the Operating Manual. The page numbers of the Operating Instruction Manual remain as in the manual.

### Basic TV Features

#### Overview of TV Buttons




#### Overview of Remote Control Buttons




### Additional TV Features

#### Using Select Mode




You can select different preset picture modes.



**1** Press the MENU button on the remote control to display the menu on the TV screen.

**2** With the cursor pointing at the  symbol on the TV screen as shown, press the yellow button.



**3** Press the blue button to select the desired mode:


-  Personal Mode - reverts to settings made in "Adjusting the Picture" section of the manual.
-  Movie Mode - for films
-  Live Mode - for live broadcast programmes

**4** Press the MENU button to remove the menu display from the TV screen.

**Note:** The mode selected in step 3 is now stored.

#### Changing Modes Quickly


- 1** Press the  button on the remote control to display the three different modes.
- 2** Press the  button again to select your desired mode.













## Additional TV Features


### Adjusting the Picture

Although the picture is adjusted at the factory, you can modify it to suit your own requirement.



- 1 Press the  button on the remote control to display the three different modes on the TV screen.
- 2 Press the  button to highlight the personal mode symbol  as shown.
- 3 Press the MENU button to display the menu on the TV screen.
- 4 Press the blue button on the control to select the  symbol on the TV screen then press the yellow button.
- 5 Press the blue button to select the item you wish to change (see below).
- 6 Press the red or yellow button to alter the selected item.
- 7 Press the MENU button to remove the menu display from the TV screen.


Symbol	Item
	• Contrast
	• Colour
	• Brightness
	• Sharpness
	• Reset - resets to factory preset picture level
	• Represents the mode selected in the "Using Select Mode" section.




## Additional TV Features

### Using the Sleep Timer


The TV may be set to switch automatically to the standby mode after a length of time chosen by you. You may set the time in 15 minute steps up to 4 hours.




- 1 Press the MENU button on the remote control to display the menu on the TV screen.
- 2 Press the blue button on the control to select the  symbol on the TV screen, then press the yellow button.
- 3 Press the yellow button repeatedly until the required amount of time delay appears on the screen.
- 4 Once the time delay has been selected, press the MENU button to remove the on-screen display.

One minute before standby, the display shown appears on the screen.


#### Notes:




- When watching TV, press the  button to display time remaining.
- To return to normal operation from standby mode, press the I/⏻ button.




# Using the Wake Up Timer


The TV may be set to switch on automatically after a length of time chosen by you. You may set the time in 15 minute steps up to 12 hours.



- 1 Press the MENU button on the remote control to display the menu on the TV screen.
- 2 Press the blue button on the control to select the  symbol on the TV screen, then press the yellow button.
- 3 Press the blue button on the control to select the  symbol on the TV screen, then press the yellow button.
- 4 Press the red or yellow button to set the time.  
  
0:00 (OFF) 0:15 0:30 0:45 -----12:00
- 5 Press the standby button .  
The standby indicator on the TV flashes regularly to indicate that the Wake Up Timer is active. After the selected length of time, the TV switches on automatically.


Notes:

- If you use the “Wake Up Timer” to switch the TV on and for one hour after switching on, no TV or Remote Control button is pressed, the TV switches itself back into Standby mode and the indicator  on the TV lights.
- Any temporary power failure will cause a misfunction in the “Wake Up Timer” and you will have to reset the “Wake Up Timer”.





# Viewing Teletext (KV-21T5D only)

Teletext is an information service transmitted by most TV stations.





## Selecting Teletext



- 1 Press a number button on the remote control to select the channel which carries the teletext service you wish to receive.
- 2 Press the  button on the remote control to switch on teletext.
- 3 Input three digits for the page number using the numbered buttons on the control.
- 4 Press the  button to switch off teletext.


**Note:** Teletext errors may occur if the broadcasting signals are weak.

## Using Other Teletext Functions

**To Superimpose Teletext on to the TV**  
Press  once in teletext mode or twice in TV mode to superimpose teletext on to the TV screen.  
Press  again to cancel teletext mode.

**To Move to Next or Preceding Page**  
Press PROGR +/- on the remote control to select the previous or next page.

**To Freeze a Teletext Page**  
Press  on the control to freeze the page.  
Press  again to cancel the freeze.

**Revealing concealed information (eg: answers to a quiz).**  
Press  to reveal information.  
Press again to conceal the information.


**Using colour buttons to access pages (Fastext)**  
When the colour coded menu appears at the bottom of a page, press the colour button (green, red, yellow or blue) to access the corresponding page.











## Exchanging Programme Positions

After tuning you may wish to change the order in which the channels appear on the TV. You may wish for example to exchange the channel on programme number 8 with the channel on programme number 4.




- 1 Press the MENU button on the remote control.
- 2 Press the blue button on the control to select  $\Upsilon$  on the TV screen, then press the yellow button.
- 3 Press the blue button to select  $\Upsilon$  then press the yellow button.
- 4 With the cursor pointing at PROGR on the TV screen as shown, press PROGR + or - button until the channel you wish to rearrange appears on screen, then press the blue button once.
- 5 Press the red or yellow button to select the new programme number (e.g. PROGR 04) for your selected channel.
- 6 Press the blue button to select  $\Upsilon$  then press the yellow button to exchange the channels.
- 7 Repeat steps 4 to 6 if you wish to change the order of the other channels on your TV, then press MENU to return to normal TV screen.
- 8 Press the PROGR +/- button to view your selected channels on their new programme numbers.





## Manually Tuning the TV

You have already tuned the TV to receive all available channels using the 'Automatically Tuning the TV' procedure at the start of this manual. You can however carry out this operation manually using the following instructions.




- 1 Press the MENU button on the remote control to display the menu on the TV screen.
- 2 Press the blue button to select the  $\Upsilon$  symbol on the TV screen then press the yellow button.
- 3 With the cursor pointing at PROGR on the TV screen as shown, press PROGR + or - button on the remote control to allocate a programme number to the channel (eg PROGR 01). For double digit numbers e.g. 55, press the -/-- button on the remote control then the corresponding numbered buttons.
- 4 Press the blue button to select the tuning bar scale then press the yellow or red button once to start the channel search. (Yellow to search up the scale or red to search down). When a channel is found it appears on the TV screen.
- 5 If you do not wish to store this channel on the programme number you selected, press the yellow or red button to continue searching for the desired channel.
- 6 If this is the channel you wish to store, press the blue button to select the  $\Upsilon$  symbol on the screen then press the yellow button to store.
- 7 Repeat steps 3 to 6 if you wish to store more channels then press the MENU button to remove the menu from the TV screen.






## Fine-Tuning Channels

If a channel is slightly off tune, you can use this fine tune procedure to obtain a better picture reception.




- 1 With the channel you wish to fine-tune on the screen, press the MENU button on the remote control. The menu display appears on the TV screen.
- 2 Press the blue button on the remote control to select the  $\gamma$  symbol on the TV screen then press the yellow button.
- 3 Press the blue button to select the  $\leftarrow F \rightarrow$  symbol on the TV screen then press the red or yellow button to adjust the tuning.
- 4 Press the blue button to select the  $\nabla$  symbol on the TV screen then press the yellow button to store.
- 5 Press the MENU button to remove the menu from the TV screen.








## Skipping Programme Positions

You can programme this TV to skip any unwanted programme numbers when they are selected with the PROG +/ - buttons.



- 1 Press the MENU button on the remote control to display the menu on the TV screen.
- 2 Press the blue button on the control to select the  $\gamma$  symbol on the TV screen then press the yellow button.
- 3 With the cursor pointing at PROGR on the TV screen as shown, press PROG + or - button on the remote control to select the programme number you want to skip.
- 4 Press the blue button to select Coo on the TV menu screen then press the yellow button on the remote control.
- 5 Press the blue button to select the  $\nabla$  symbol on the TV screen then press the yellow button to store.
- 6 Repeat steps 3 to 5 to skip other unused programme positions.
- 7 Press the MENU button to remove the menu from the TV screen.



**Note:** If you wish, you can still select any skipped programme number by pressing the corresponding numbered buttons on the remote control.

Optional Connections

Using Optional Equipment

You can connect optional audio or video equipment to your TV, such as a VCR, a camcorder or video games as shown.


Select and View the Input Signal

- 1 Connect your equipment to the designated TV socket.
- 2 Press the button repeatedly on your remote control until the correct input symbol appears on the TV screen.

Symbol	Input signals
	• Audio/video input signal through the Euro AV connector <b>C</b>
	• RGB input signal through the Euro AV connector <b>C</b>
	• Audio/video input signal through the phono sockets <b>A</b>

- 3 Switch on the connected equipment.
- 4 To return to normal TV picture, press the button on the remote control.

Note: To avoid picture distortion, do not connect equipment to the **A** and **C** connectors at the same time.




Additional Information

Connecting a VCR

We recommend you tune in the VCR signal to TV programme number '0' using the 'Manually Tuning in the TV' section of this instruction manual.

Connecting Headphones

Plug in your headphones to the socket **B** on the front of the TV set.



Additional Information


Troubleshooting

Here are some simple solutions to problems which may affect the picture and sound.


Problem	Solution
No picture (screen is dark), no sound	<ul style="list-style-type: none"><li>• Plug the TV in.</li><li>• Press the  button on the front of TV.</li><li>• If the  indicator is on press  button or a programme number button on the remote control.</li><li>• Check the aerial connection.</li><li>• Check that the selected video source is on.</li><li>• Turn the TV off for 3 or 4 seconds and then turn it on again using the  button on the front of the TV.</li></ul>
Poor or no picture (screen is dark), but good sound	<ul style="list-style-type: none"><li>• Using the MENU system, select the Picture Adjustment display. Adjust the brightness, picture and colour balance levels.</li><li>• From the Picture Adjustment display select  to return to the factory settings.</li></ul>
Poor picture quality when watching a RGB video source.	<ul style="list-style-type: none"><li>• Press the  button repeatedly on the remote control until the RGB symbol  is displayed on the screen.</li></ul>
Good picture, no sound	<ul style="list-style-type: none"><li>• Press the  +/- button on the remote control.</li><li>• If  is displayed on the screen, press the  button on the remote control.</li></ul>
No colour on colour programmes	<ul style="list-style-type: none"><li>• Using the MENU system, select the Picture Adjustment display. Adjust the colour balance.</li><li>• From the Picture Adjustment display select  to return to the factory settings.</li></ul>
Distorted picture when changing programmes or selecting teletext	<ul style="list-style-type: none"><li>• Turn off any equipment connected to the 21 pin Euro connector on the rear of the TV.</li></ul>
Remote control does not function	<ul style="list-style-type: none"><li>• Replace the batteries</li></ul>
The standby indicator  on the TV flashes even though the "Wake Up Timer" is not in use.	<ul style="list-style-type: none"><li>• Contact your nearest Sony service centre.</li></ul>
<ul style="list-style-type: none"><li>• If you continue to have these problems, have your TV serviced by qualified personnel.</li><li>• NEVER open the casing yourself.</li></ul>	

## SECTION 2 DISASSEMBLY


### 2-1. REAR COVER REMOVAL




### 2-2. CHASSIS ASSY REMOVAL



### 2-3. SERVICE POSITION



## 2-4. PICTURE TUBE REMOVAL



### • REMOVAL OF ANODE-CAP


**Note :** Short circuit the anode of the picture tube and the anode cap to the metal chassis, CRT shield or carbon paint on the CRT, after removing the anode.

#### \* REMOVING PROCEDURES.

- 
- ① Turn up one side of the rubber cap in the direction indicated by the arrow (a)
  - ② Using a thumb pull up the rubber cap firmly in the direction indicated by the arrow (b)
  - ③ When one side of the rubber cap is separated from the anode button, the anode-cap can be removed by turning up the rubber cap and pulling it up in the direction of the arrow (c)

### • HOW TO HANDLE THE ANODE-CAP

- ① To prevent damaging the surface of the anode-cap do not use sharp materials.
- ② Do not apply too great a pressure on the rubber, as this may cause damage to the anode connector.
- ③ A metal fitting called a shatter hook terminal is fitted inside the rubber cap. Do not turn the rubber foot over excessively this may cause damage if the shatter hook sticks out.



## SECTION 3 SET-UP ADJUSTMENTS

- When complete readjustment is necessary or a new picture tube is installed, carry out the following adjustments.
- Unless there are specific instructions to the contrary, carry out these adjustments with the rated power supply.
- Unless there are specific instructions to the contrary, set the controls and switches to the following settings :

Contrast ..... 80% [or remote control normal]  
 Brightness ..... 50%

Carry out the following adjustments in this order :

- 3-1. Beam Landing
- 3-2. Convergence
- 3-3. White balance
- 3-4. Focus


- Note :** Test equipment required
1. Color bar/pattern generator.
  2. Degausser.
  3. Oscilloscope.
  4. Digital multimeter.
  5. DC Power supply.

### Preparation:

1. In order to reduce the influence of geomagnetism on the set's picture tube, face it in an easterly or westerly direction.
2. Switch on the TV set's power and degauss with the degausser.



### 3-1. BEAM LANDING

1. Input an all-white signal from the pattern generator. Set the Contrast and Brightness to normal.
2. Set the pattern generator raster signal to all Red.
3. Move the deflection yolk forward and adjust with the purity control so that the Red is at the centre and the Blue and Green take up equally sized areas on each side of the screen. [See Fig.3-1 - 3-3].
4. Move the deflection yolk forward and adjust so that the entire screen becomes Red. [See Fig.3-1].
5. Switch the raster signal to Blue, then to Green and verify the purity condition.
6. When the position of the deflection yolk has been determined, fasten the deflection yolk with the screws.
7. If the beam does not land correctly in all the corners, use magnets to correct it. [See Fig.3-4].




**Fig. 3-1**

**Fig. 3-2**



**Fig. 3-3**




**Fig. 3-4**

## 3-2. CONVERGENCE

### Preparation:


- Before starting this adjustment, adjust the focus, horizontal size and vertical size.
- Minimize the Brightness setting.
- Input a dot pattern from the pattern generator.

#### (1) Horizontal and vertical static convergence




1. [Moving horizontally], adjust the H.STAT control so that the Red, Green and Blue points are on top of each other at the centre of the screen.
2. [Moving vertically], adjust the V.STAT magnet so that the Red, Green and Blue points are on top of each other at the centre of the screen.
3. If the H.STAT variable resistor is unable to bring the Red, Green and Blue points together at the centre of the screen, adjust the horizontal convergence with the H.STAT variable resistor and the V.STAT magnet in the manner indicated below. [In this case, the H.STAT variable resistor and the V.STAT magnet influence each other].


- Tilt the V.STAT magnet and adjust the static convergence by opening or closing the V.STAT magnet.




4. If the V.STAT magnet is moved in the direction of the (a) and (b) arrows, the Red, Green and Blue points move as indicated below.



## (2) Operation of the BMC (Hexapole) magnet.




- The respective dot position resulting from moving each magnet interact, so be sure to perform adjustment whilst tracking.  
Use the H.STAT VR to adjust the Red, Green and Blue dots so that they coincide at the centre of the screen [by moving the dots in the horizontal direction].



## (3) Dynamic convergence adjustment.

### Preparation:




- Before starting this adjustment, adjust the horizontal and vertical static convergence.
- Slightly loosen the deflection yolk screws.
- Remove the deflection yolk spacer.
- Move the deflection yolk as indicated in the figure below and optimize the convergence.
- Tighten the deflection yolk screws.
- Re-install the deflection yolk spacer.





**(4) Screen corner convergence.**

- If you are unable to adjust the corner convergence properly, this can be corrected by the use of permalloy assemblies.



### 3-3. Screen [G2], White balance

#### G2 Setting

- Input a dot signal from the pattern generator.
- Set the Picture, Brightness and Colour to minimum.
- Apply 170Vdc from an external power supply to the R, G and B cathodes of the CRT.
- Whilst watching the picture, adjust the G2 control [RV SCREEN] located on the FBT to the point just before the fly-back return lines disappear.

#### White balance adjustment

- Input a 'PAL' all-white signal from the pattern generator.
- Enter into the Service Mode.
- Enter into the 'Picture' service menu.
- Select the 'Green drive' and adjust so that the White Balance becomes optimum.
- Select the 'Blue drive' and adjust so that the White Balance becomes optimum.
- Set the Picture to MIN.
- Set the 'R-cut-off' to 07.
- Adjust the 'G-cut-off', and the 'B-cut-off' so that the White Balance becomes optimum.
- Press the ☐ button to return to TV operation.

#### PICTURE

R - Drive	Adj
G - Drive	Adj
B - Drive	Adj
R - cut - off	Adj
G - cut - off	Adj
B - cut - off	Adj
ID - start	02
ID - stop	01
ID - level	01
Bellfo	Adj
Sub Colour	Adj
Sub Brightness	Adj

### 3-4. FOCUS

- Input a Phillips colour pattern
- Set the picture settings to normal.
- Adjust the focus control located on the Flyback transformer to bring the centre of the screen into focus.

**Note** :Bring only the centre area of the screen into focus, switch to an all-white pattern and confirm that the magenta ring is hardly noticed. To obtain optimum focus balance the focus setting between optimum screen centre focus and a reduced magenta ring level.


## SECTION 4 CIRCUIT ADJUSTMENTS

### 4-1. ELECTRICAL ADJUSTMENTS

Service adjustments to this model can be performed using the supplied Remote Commander RM-883.

#### HOW TO ENTER INTO SERVICE MODE

1. Turn on the main power switch and enter into the stand-by mode.
2. Press the following sequence of buttons on the Remote Commander.



- 'TT--' will appear in the upper right corner of the screen.  
Other status information will also be displayed.
3. Press 'MENU' on the remote commander to obtain the following menu on the screen.

TEST MENU
> Picture
Geometry
Sound
TV Status
AGC Adjust
Technical

4. Move to the corresponding adjustment item using the 'Green' [up] or 'Blue' [down] buttons on the Remote Commander.
5. Press the 'Yellow' button to enter into the required menu item.
6. Press the 'Menu' button on the Remote Commander to quit the Service Mode when all adjustments have been completed.

**Note :** The data shown in the 'TV STATUS' table is dependant on destination and country.

#### PICTURE

R - Drive	Adj
G - Drive	Adj
B - Drive	Adj
R - cut - off	Adj
G - cut - off	Adj
B - cut - off	Adj
ID - start	02
ID - stop	01
ID - level	01
Bell-f0	Adj
Sub Colour	Adj
Sub Brightness	Adj

#### GEOMETRY

V centre	Adj
V size	Adj
V Lin	Adj
S Corr	Adj
H Cent	Adj
H Size	Adj
Pin Amp	Adj
Corner Pin	Adj
Pin Phase	Adj
V Bow	Adj
V Angle	Adj
Upper V Lin	Adj
Lower V Lin	Adj
Left HBLK	07
Right HBLK	07
CD Mode (AV)	01

#### SOUND

Nicam Error Lower	20
Nicam Error Upper	80
Nicam Error Rate	xx [Status only]
AGC Gain Level	xx [Status only]

#### TV STATUS

Destination	A/L/E/U/D/B/K/R
Text Language	East/West

#### TECHNICAL


GD - Secam	30
BD - Secam	31
RC - Secam	11
GC - Secam	19
BC - Secam	10
GD - Sports	30
BD - Sports	36
RC - Sports	14
GC - Sports	15
BC - Sports	17
Y - Delay (AV)	07

#### SUB BRIGHTNESS ADJUSTMENT

1. Input a Phillips colour pattern.
2. Press 'TEST' 'TEST' 13 on the Remote Commander.
3. Adjust the 'Sub-Brightness' data so that there is barely a difference between the 0 IRE and 10 IRE signal levels.


#### SUB CONTRAST ADJUSTMENT

1. Input a video signal that contains a small 100% white area on a black background
2. Set the picture control to maximum. ['TT01']
3. Connect an oscilloscope to Pin 1 of CN504 [A Board].
4. Enter into the 'Picture' service menu.
5. Adjust the 'R - Drive' data to obtain the following waveform.



#### SUB COLOUR ADJUSTMENT

1. Receive a PAL colour bar signal.
2. Connect an oscilloscope to Pin 3 of CN504 [A Board].
3. Enter into the 'Picture' service menu.
4. Adjust the 'Sub Colour' data so that the Cyan, Magenta and Blue colour bars are of equal levels as indicated below.



**Note:** Ensure that no signal is applied to the Antenna socket while carrying out the following IF adjustments.

#### SYSTEM B/G, D/K, I & L I.F ADJUSTMENT


1. Input a 38.9Mhz carrier signal at 100dBuV to Pin 11 [IF output] of the tuner [TU101].
2. Measure the voltage at Pin 17 of [IC101].
3. Adjust L103 [A Board] to obtain a voltage of 2.5V +/- 0.3V.

#### SYSTEM L BAND 1 I.F ADJUSTMENT

1. Input a 34.0MHz carrier signal at 100dBuV to Pin 11 [IF output] of the tuner [TU101].
2. Select 'system L' + C00 [channel 00].
3. Measure the voltage at Pin 17 [IC101].
4. Adjust RV101 [A Board] to obtain a voltage of 2.5V +/- 0.3V.

#### TUNER AGC ADJUSTMENT


1. Receive a signal of 65dBuV / 75 ohm terminated, via the tuner antenna socket.
2. Connect a voltmeter to JW130 [A Board].
3. Enter into the 'Test Menu'.
4. Select the 'AGC Adjust' menu item.
5. Adjust the data using the Yellow and Green buttons on the Remote Commander to obtain a voltage of 3.0V +/- 0.2V.



## BELL FILTER ADJUSTMENT (Secam models only).

**Note :** Ensure that the TV set has been powered up for at least 1 minute to allow for drift before carrying out the following adjustment.

1. Input a video SECAM Colour Bar signal via AV1.
2. Connect an oscilloscope to pin 1 of CN504 [R-OUT] on the A board.
3. Enter into the 'Picture' menu and select 'Bell-f0'.
4. Decrease the register of 'Bell-f0' until the following waveform change between RED and BLUE is obtained.




5. When the correct waveform has been obtained add an additional 7 steps to the register.

## DEFLECTION SYSTEM ADJUSTMENT

1. Enter into the 'Geometry' service menu.
2. Select and adjust each item in order to obtain the optimum image.

### GEOMETRY

V centre	Adj
V size	Adj
V Lin	Adj
S Corr	Adj
H Cent	Adj
H Size	Adj
Pin Amp	Adj
Corner Pin	Adj
Pin Phase	Adj
V Bow	Adj
V Angle	Adj
Upper V Lin	Adj
Lower V Lin	Adj
Left HBLK	07
Right HBLK	07
CD Mode (AV)	01



## 4-2. TEST MODE 2:

Is available by pressing 'TEST' button twice, OSD 'TT' appears. The functions described below are available by pressing the two numbers. To release the Test mode 2, press 0 twice, or switch the TV into stand-by mode, or press the ☐ TV button on the remote commander.

00	Cancel Test mode
01	Picture maximum
02	Picture minimum
03	Volume 35%
04	Volume 50%
05	Volume 65%
06	Volume 80%
07	Ageing mode On/Off
08	Set shipping conditions
09	Display TV Status
10	No function
11	Sub Picture Adjustment
12	Sub Colour Adjustment
13	Sub Brightness Adjustment
14	Text H position Adjustment
15	Rotation test
16	Picture level 50%
17	Audio mute ON
18	Disable Blanking
19	No function
20	No function
21	Destination A
22	Destination L
23	Destination E
24	Destination U
25	Destination D
26	Destination B
27	Destination K
28	Destination R
29	No function
30	No function
31	Auto shutoff Disable/Enable
32	RGB priority Disable/Enable
33	Rotation On/OFF
34	Text language East/West
35	Wide CRT/4:3 CRT
36	VM ON/OFF test
37	No function
38	No function
39	No function
40	No function
41	Re-initialize the NVM [Only when Prog=59]

42	Re-initialise geometry settings [Only when Prog=59]
43	No function
44	No function
45	No function
46	No function
47	No function
48	Set NVM as NON Virgin [Only when Prog=59]
49	Set NVM as Virgin [Only when Prog=59]
50	No function
51	No function
52	No function
53	No function
54	No function
55	No function
56	No function
57	No function
58	No function
59	No function
60	No function
61	Auto AGC Adjust
62	Alternative Dest B Autotuning
63	Enable/Disable Y/C input
64	Signal Quality Check for Auto Tune
65	Signal Quality NOT Checked for Auto Tune
66	No function
67	Manual AGC Adjust
68 -100	No function


4-3. FE-1 SELF DIAGNOSTIC SOFTWARE

The identification of errors within the FE-1 chassis is triggered in one of two ways :- 1: Busy or 2: Device failure to respond to IIC. In the event of one of these situations arising the software will first try to release the bus if busy (Failure to do so will report with continuous flashing LED) and then communicate with each device in turn to establish if a device is faulty. If a device is found to be faulty the relevant device number will be displayed through the LED (Series of flashes which must be counted) See Table 1., non fatal errors are reported using this method. Each time the software detects an error it is stored within the NVM. See Table 2.

Table 1


ERROR	LED ERROR COUNT
No error	00
Not allowed (may be confused with Sircs response flash!)	01
Protection circuit trip < ANY TIME >	02
Reserved	03
No vertical sync	04
AKB	05
IIC bus clock and/or data lines low at Power ON	06
NVM no IIC bus acknowledge at Power ON	07
Jungle controller no IIC acknowledge at Power ON	08
Tuner no acknowledge at Power ON	09
Sound processor no acknowledge at Power ON	10

Flash Timing Example : e.g. error number 3



How to enter into Table 2

1. Turn on the main power switch of the TV set and enter into the 'Standby Mode'.
2. Press the following sequence of buttons on the Remote Commander.





3. The following table will be displayed indicating the error count.

Table 2

Error	Times
2	-
3	-
4	-
5	-
6	-
7	-
8	-
9	-
10	-


**Note:** To clear the error count data press '80' on the Remote commander.

5-1 BLOCK DIAGRAMS





5-2. CIRCUIT BOARD LOCATION



5-3. SCHEMATIC DIAGRAMS AND PRINTED WIRING BOARDS

Note :

- All capacitors are in  $\mu\text{F}$  unless otherwise noted.
- $\text{pF}$  :  $\mu\text{F}$  50WV or less are not indicated except for electrolytic types.
- Indication of resistance, which does not have one for rating electrical power, is as follows.

Pitch : 5mm  
Electrical power rating : 1/4W

- Chip resistors are 1/10W
- All resistors are in ohms.  
k = 1000 ohms, M = 1000,000 ohms

- : nonflammable resistor.
- : fusible resistor.
- : internal component.
- : panel designation or adjustment for repair.

- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- All voltages are in Volts.
- Readings are taken with a 10Mohm digital mutimeter.
- Readings are taken with a color bar input signal.
- Voltage variations may be noted due to normal production tolerances.

- : B + bus.
- : B - bus.
- : RF signal path.
- : earth - ground.
- : earth - chassis.

Reference Information

RESISTOR	RN	: METAL FILM
	RC	: SOLID
	FPRD	: NON FLAMMABLE CARBON
	FUSE	: NON FLAMMABLE FUSIBLE
	RS	: NON FLAMMABLE METAL OXIDE
	RB	: NON FLAMMABLE CEMENT
	RW	: NON FLAMMABLE WIREWOUND
		: ADJUSTMENT RESISTOR
COIL	LF-8L	: MICRO INDUCTOR
CAPACITOR	TA	: TANTALUM
	PS	: STYROL
	PP	: POLYPROPYLENE
	PT	: MYLAR
	MPS	: METALIZED POLYESTER
	MPP	: METALIZED POLYPROPYLENE
	ALB	: BIPOLAR
	ALT	: HIGH TEMPERATURE
	ALR	: HIGH RIPPLE


Note : The components identified by shading and marked are critical for safety. Replace only with the part numbers specified in the parts list.

Note : Les composants identifiés par une trame et par une marque sont d'une importance critique pour la sécurité. Ne les remplacer que par des pièces de numéro spécifié.


A

POWER SUPPLY, DEFLECTION, TUNING, PROCESSOR, VIDEO SIGNAL PROCESSOR, AV IN/OUT


A Board







WAVEFORMS A BOARD





A BOARD IC VOLTAGE TABLE

Ref No	Pin No	Voltage (V)	Ref No	Pin No	Voltage (V)	Ref No	Pin No	Voltage (V)
IC001	4	0.8	IC101	5	2.8	IC301	20	3.8
	6	3.2		6	2.7		21	1.6
	7	4.8		7	3.9		22-24	1.5
	8	0.3		8	2.2		26-28	4.5
	9	0.3		9	2.0		30	4.5
	10	2.0		10	2.0		31-32	4.4
	11	1.5		11	1.5		33	8.1
	12	4.7		12	0.3		34-35	3.3
	13	3.6		13	2.6		41	5.0
	14	4.7		14	4.7		42	8.6
	15	3.6		15	2.6		43	5.0
	16	4.7		16	4.7		44	8.8
	17	3.6		17	2.6		45	5.2
	18	4.7		18	4.7		46	1.5
IC002	19	3.6	IC201	19	3.6	IC501	19	3.6
	20	4.7		20	4.7		20	3.8
	21	3.6		21	3.6		21	1.6
	22	4.7		22	4.7		22-24	1.5
	23	3.6		23	3.6		26-28	4.5
	24	4.7		24	4.7		30	4.5
	25	3.6		25	3.6		31-32	4.4
	26	4.7		26	4.7		33	8.1
	27	3.6		27	3.6		34-35	3.3
	28	4.7		28	4.7		41	5.0
	29	3.6		29	3.6		42	8.6
	30	4.7		30	4.7		43	5.0
	31	3.6		31	3.6		44	8.8
	32	4.7		32	4.7		45	5.2
IC003	33	3.6	IC301	33	3.6	IC501	33	3.6
	34	4.7		34	4.7		34	3.8
	35	3.6		35	3.6		35	1.6
	36	4.7		36	4.7		36-38	1.5
	37	3.6		37	3.6		40	4.5
	38	4.7		38	4.7		41	5.0
	39	3.6		39	3.6		42	8.6
	40	4.7		40	4.7		43	5.0
	41	3.6		41	3.6		44	8.8
	42	4.7		42	4.7		45	5.2
	43	3.6		43	3.6		46	1.5
	44	4.7		44	4.7		47	1.4
	45	3.6		45	3.6		48	1.5
	46	4.7		46	4.7		49	5.2
IC004	47	3.6	IC301	47	3.6	IC501	47	3.6
	48	4.7		48	4.7		48	3.8
	49	3.6		49	3.6		49	1.6
	50	4.7		50	4.7		50-52	1.5
	51	3.6		51	3.6		54	4.5
	52	4.7		52	4.7		55	2.8
	53	3.6		53	3.6		56	2.0
	54	4.7		54	4.7		57	7.3
	55	3.6		55	3.6		58	8.8
	56	4.7		56	4.7		59	-60.0
	57	3.6		57	3.6		60	-51.3
	58	4.7		58	4.7		61	-58.0
	59	3.6		59	3.6			
	60	4.7		60	4.7			

A BOARD \* MARK

Ref	21MSD	21MSK	21TSD	21TSK	21TSR
C606	220MF 400V	220MF 400V	220MF 400V	220MF 400V	220MF 450V
C638	10MF 400V	10MF 450V	10MF 400V	10MF 450V	10MF 450V
CP102	1-567-101-11	-	1-567-101-11	1-567-101-11	1-567-101-11
CP104	-	TRAP CERAMIC 6.5MHZ	-	TRAP CERAMIC 6.5MHZ	TRAP CERAMIC 6.5MHZ
D103	-	DAN202K	-	DAN202K	DAN202K
IC001	SAAS481PS/M1A/088	SAAS481PS/M1A/088	SAAS481PS/M1A/088	SAAS481PS/M1A/088	SAAS481PS/M1A/088
Q104	-	DTC144EK	-	DTC144EK	DTC144EK
Q105	-	DTC144EK	-	DTC144EK	DTC144EK
R114	-	3.3K	-	3.3K	3.3K
R115	-	3.3K	-	3.3K	3.3K
R135	-	560	-	560	560
R150	-	100	-	100	100
SWF101	FILTER, SURFACE WAVE	FILTER, SURFACE WAVE	FILTER, SURFACE WAVE	FILTER, SURFACE WAVE	FILTER, SURFACE WAVE


C Board



C BOARD TRANSISTOR VOLTAGE TABLE


Ref No	(B) Base	(C) Collector	(E) Emitter
Q702	1.5	8.3	1.1
Q703	8.8	169.8	8.3
Q704	169.5	1.9	209.5
Q705	1.5	8.3	1.1
Q706	8.8	170.7	8.3
Q707	170.5	1.9	215.7
Q708	1.5	8.3	1.0
Q709	8.9	171.3	8.3
Q710	171.2	1.9	206.3

WAVEFORMS C BOARD




5-4 SEMICONDUCTORS


LM393N  
TDA2822M  
TEA2124




SE-135N  
SE-135N-LF12



SAA5498PS/M1A/079  
SAA5498PS/M1A/080  
SAA5498PS/M1A/081  
SAA5498PS/M1A/088



SBX1981-51




STR-F6654




STV9379




ST24W08FM6TR




TDA7494




TDA9817-V1




TOP209P




TYA7805CTV



BF421-AMMO



DTC114EK  
DTC114EKA-T146  
DTC144EKA-T146R  
2SA1037K-T-146-QR  
2SC2412K-QR  
2SC2412K-T-146-R




2SC688-LK




2SA933AS-QRT  
2SA933AS-RT  
2SC1740S-RT



AK04V1




AK04V1




AK04V1

AK04V1


DAN202K  
DAN202K-T146




D45B60L-F



AK04V0



AK04V0



AK04V0



AK04V0


AK04V0

AK04V0


AK04V0

5-5. IC BLOCK DIAGRAMS


A BOARD IC501 STV 9379




A BOARD IC201 TDA7495




A BOARD IC101 TDA9817/V1




A BOARD IC606 STR-F6654




A BOARD IC301 CXA2060AS



## WAVEFORMS A BOARD




## WAVEFORMS C BOARD






## 5-4 SEMICONDUCTORS


LM393N  
TDA2822M  
TEA2124




SE-135N  
SE-135N-LF12




SAA5498PS/M1A/079  
SAA5498PS/M1A/080  
SAA5498PS/M1A/081  
SAA5498PS/M1A/088




SBX1981-51




STR-F6654




STV9379




ST24W08FM6TR




TDA7494




TDA9817-V1



TOP209P




TYA7805CTV




BF421-AMMO  
2SA1091-O




DTC114EK  
DTC114EKA-T146  
DTC144EKA-T-146R  
2SA1037K-T-146-QR  
2SC2412K-QR  
2SC2412K-T-146-R



2SC688-LK




2SA933AS-QRT  
2SA933AS-RT  
2SC1740S-RT




AK04-V1  
AU-01Z-V1  
DINL20-TA  
ERB44-06TP1  
EG-1Z-V1  
EL1Z  
ERD28-06S  
ERC04-06SE  
ERC06-15S  
FMN-G12S


GP08DPKG23  
GP10GPKG23  
GP15GPKG23  
LSB360HL  
RB501V-40TE-T7  
RG1CLF-B1  
RGPO2-17EL-6433  
RGP15GPKG23  
RGP10GPKG23  
RU-4AM-T3



DAN202K  
DAN202K-T146




D45B60L-F




AK04VO  
AK04WS  
ERC04-6SE  
HZS9.1NB2  
MTZJ-T-77-4.7B  
MTZJ-T-77-5.6B  
MTZJ-T-77-12B  
MTZJ-T-77-22B

MTZJ-T-77-33A  
P6KE200AG23  
RD5.6ESB2  
RD6.8ES-B2  
RN3Z-LF014-302  
1SS119-25TD  
1SS133T-77




UF4005PKG23




## 5-5. IC BLOCK DIAGRAMS


A BOARD IC501 STV 9379




A BOARD IC201 TDA7495




A BOARD IC101 TDA9817/V1



A BOARD IC606 STR-F6654



A BOARD IC301 CXA2060AS



## SECTION 6 EXPLODED VIEWS


**Note :** Les composants identifiés par une trame et par une marque  $\Delta$  sont d'une importance critique pour la sécurité. Ne les remplacer que par des pièces du numéro spécifié.

**Note :** The components identified by shading and marked  $\Delta$  are critical for safety. Replace only with the part numbers specified in the parts list.

### NOTE :


- Items with no part number and no description are not stocked because they are seldom required for routine service.
- The construction parts of an assembled part are indicated with a collation number in the remarks column.
- Items marked “\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

### 6-1. CHASSIS



REF. NO.	PART.NO	DESCRIPTION	REMARK	REF. NO.	PART.NO	DESCRIPTION	REMARK
1	$\Delta$ 1-571-433-21	SWITCH, PUSH (AC POWER)			*A-1632-812-A	A BOARD, COMPLETE (KV-21T5D)	
2	4-202-531-01	AC CORD LOCK (SC)			*A-1632-813-A	A BOARD, COMPLETE (KV-21T5K)	
3	$\Delta$ 1-590-501-21	CORD, POWER (WITH NOISE FILTER)			*A-1632-810-A	A BOARD, COMPLETE (KV-21T5R)	
4	$\Delta$ 1-453-279-11	TRANSFORMER ASSY, FLYBACK (NX-1747/U2B)		7	4-204-349-01	BRACKET, BOTTOM	
5	8-598-331-02	TUNER (VSS BT-AC401)		8	4-204-345-01	COVER, REAR	
6	*A-1632-811-A	A BOARD, COMPLETE (KV-21M5D)		9	4-039-358-01	SCREW (4 X 16), (+) BV, TAPPING	
	*A-1632-809-A	A BOARD, COMPLETE (KV-21M5K)					

6-2. PICTURE TUBE



**Note :** Les composants indentifies par une trame et par une marque Δ sont d'une importance critique pour la securite. Ne les remplacer que par des pieces du numero specifie.

**Note :** The components identified by shading and marked Δ are critical for safety. Replace only with the part numbers specified in the parts list.

REF.NO.	PART.NO	DESCRIPTION	REMARK	REF.NO.	PART.NO	DESCRIPTION	REMARK
51	X-4200-415-1	BEZNET ASSY	53-57	62	4-200-433-01	SPRING, EXTENSION	
52	4-204-347-01	DOOR, CONTROL (KV-21M5D/21M5K)		63	Δ 1-416-329-11	COIL, DEMAGNETIC	
	4-204-347-11	DOOR, CONTROL (KV-21T5D/21T5K/21T5R)		64	4-386-622-01	BAND, DGC	
53	4-202-555-01	SHAFT, DOOR		65	Δ 1-540-006-22	CAP ASSY, HIGH VOLTAGE	
54	4-047-464-01	CATCHER, PUSH		66	4-203-648-01	SCREW (5), SELF TAPPING	
55	4-204-346-01	BUTTON, POWER		67	1-598-128-11	SPEAKER	
56	4-202-964-01	SPRING		68	4-039-358-01	SCREW (4X16), (+)BV TAPPING	
57	4-204-348-01	LIGHT, GUIDE		69	4-308-870-00	CLIP, LEAD WIRE	
58	Δ 8-738-784-05	PICTURE TUBE (SD-169) (A51JXH61X)		70	1-425-032-00	MAGNET, DISK; 10MM Ø	
59	Δ 8-451-295-45	DEFLECTION YOKE (Y21PFA2BA)		71	1-452-094-00	MAGNET, ROTATABLE DISK; 15MM Ø	
60	*A-1638-115-A	C BOARD COMPLETE		72	X-4387-214-1	PERMALLOY ASSY, CORRECTION	
61	Δ 8-738-784-72	ITC	58-59	73	3-701-007-00	BAND, BINDING	

## SECTION 7 ELECTRICAL PARTS LIST

**Note :** Les composants identifiés par une trame et par une marque  $\Delta$  sont d'une importance critique pour la sécurité. Ne les remplacer que par des pièces du numéro spécifié.

**Note :** The components identified by shading and marked  $\Delta$  are critical for safety. Replace only with the part numbers specified in the parts list.

- Items marked “\*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- RESISTORS**
- All resistors are in ohms.
- F : nonflammable.

When indicating parts by reference number, please include the board name.

**CAPACITORS**  
MF : mF, PF : mmF

**COILS**  
MMH : mH , uH

A

REF.NO.	PART.NO	DESCRIPTION	REMARK	REF.NO.	PART.NO	DESCRIPTION	REMARK
	*A-1632-811-A	A BOARD, COMPLETE (KV-21M5D) *****		C033	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
	*A-1632-809-A	A BOARD, COMPLETE (KV-21M5K) *****		C035	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
	*A-1632-812-A	A BOARD, COMPLETE (KV-21T5D) *****		C036	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
	*A-1632-813-A	A BOARD, COMPLETE (KV-21T5K) *****		C037	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
	*A-1632-810-A	A BOARD, COMPLETE (KV-21T5R) *****		C038	1-126-964-11	ELECT 10MF	20% 50V
	4-203-258-01	HOLDER, LED		C039	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
	4-382-854-01	SCREW (M3X8), P, SW (+)		C040	1-163-001-11	CERAMIC CHIP 220PF	10% 50V
	4-382-854-11	SCREW (M3X10), P, SW (+)		C041	1-163-205-00	CERAMIC CHIP 0.001MF	10% 50V
	< CAPACITOR >			C042	1-126-933-11	ELECT 100MF	20% 16V
C001	1-104-665-11	ELECT 100MF	20% 25V	C043	1-126-935-11	ELECT 470MF	20% 16V
C002	1-126-965-11	ELECT 22MF	20% 50V	C101	1-164-665-11	CERAMIC CHIP 0.039MF	10% 50V
C004	1-163-038-00	CERAMIC CHIP 0.1MF	25V	C102	1-164-665-11	CERAMIC CHIP 0.039MF	10% 50V
C005	1-163-105-00	CERAMIC CHIP 33PF	5% 50V	C103	1-104-665-11	ELECT 100MF	20% 25V
C006	1-163-105-00	CERAMIC CHIP 33PF	5% 50V	C105	1-126-965-11	ELECT 22MF	20% 50V
C007	1-126-935-11	ELECT 470MF	20% 16V	C106	1-163-117-00	CERAMIC CHIP 100PF	5% 50V
C008	1-126-964-11	ELECT 10MF	20% 50V	C107	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C009	1-126-965-11	ELECT 22MF	20% 50V	C108	1-163-465-11	CERAMIC CHIP 9PF	0.25PF 50V
C011	1-126-965-11	ELECT 22MF	20% 50V	C109	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V
C012	1-126-959-11	ELECT 0.47MF	20% 50V	C110	1-163-038-00	CERAMIC CHIP 0.1MF	25V
C013	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V	C111	1-216-296-00	SHORT 0	
C016	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C112	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
C018	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C113	1-126-965-11	ELECT 22MF	20% 50V
C019	1-163-038-00	CERAMIC CHIP 0.1MF	25V	C114	1-163-037-11	CERAMIC CHIP 0.022MF	10% 50V
C022	1-126-935-11	ELECT 470MF	20% 16V	C115	1-164-489-11	CERAMIC CHIP 0.22MF	10% 16V
C024	1-104-665-11	ELECT 100MF	20% 25V	C116	1-126-961-11	ELECT 2.2MF	20% 50V
C025	1-104-664-11	ELECT 47MF	20% 10V	C117	1-126-961-11	ELECT 2.2MF	20% 50V
C029	1-163-077-00	CERAMIC CHIP 0.1MF	10% 25V	C118	1-163-038-00	CERAMIC CHIP 0.1MF	25V
C030	1-104-665-91	ELECT 470MF	20% 6.3V	C119	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V
C031	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V	C120	1-163-031-11	CERAMIC CHIP 0.01MF	50V
C032	1-163-077-00	CERAMIC CHIP 0.1MF	10% 25V	C126	1-163-101-00	CERAMIC CHIP 22PF	5% 50V
				C127	1-164-005-11	CERAMIC CHIP 0.47MF	16V
				C128	1-164-005-11	CERAMIC CHIP 0.47MF	16V
				C129	1-104-664-11	ELECT 47MF	20% 16V
				C130	1-164-005-11	CERAMIC CHIP 0.47MF	16V
				C131	1-163-038-00	CERAMIC CHIP 0.1MF	25V



REF. NO.	PART.NO	DESCRIPTION	REMARK	REF. NO.	PART.NO	DESCRIPTION	REMARK
C134	1-128-551-11	ELECT 22MF	20% 25V	C350	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C135	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C351	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C138	1-165-319-11	CERAMIC CHIP 0.1MF	50V	C401	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C139	1-163-031-11	CERAMIC CHIP 0.01MF	50V	C402	1-126-960-11	ELECT 1MF	20% 50V
C140	1-163-031-11	CERAMIC CHIP 0.01MF	50V	C403	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C141	1-163-105-00	CERAMIC CHIP 33PF	5% 50V	C405	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C142	1-104-664-11	ELECT 47MF	20% 16V	C406	1-126-960-11	ELECT 1MF	20% 50V
C143	1-104-664-11	ELECT 47MF	20% 25V	C407	1-126-964-11	ELECT 10MF	20% 50V
C146	1-163-031-11	CERAMIC CHIP 0.01MF	50V	C408	1-126-964-11	ELECT 10MF	20% 50V
C160	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V	C410	1-126-964-11	ELECT 10MF	20% 50V
C201	1-104-666-11	ELECT 220MF	20% 25V	C426	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V
C203	1-126-942-61	ELECT 1000MF	20% 25V	C427	1-535-303-00	LEAD, JUMPER (5.0MM)	
C206	1-126-960-11	ELECT 1MF	20% 50V	C433	1-163-141-00	CERAMIC CHIP 0.001MF	5% 50V
C207	1-126-972-11	ELECT 1000MF	20% 50V	C434	1-126-935-11	ELECT 470MF	20% 16V
C209	1-163-037-11	CERAMIC CHIP 0.022MF	10% 50V	C437	1-126-960-11	ELECT 1MF	20% 50V
C210	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C445	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V
C211	1-163-009-11	CERAMIC CHIP 0.001MF	10% 50V	C501	1-126-968-11	ELECT 100MF	20% 50V
C214	1-163-019-00	CERAMIC CHIP 0.0068MF	10% 50V	C502	1-163-038-00	CERAMIC CHIP 0.1MF	25V
C215	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C503	1-126-968-11	ELECT 100MF	20% 50V
C301	1-163-038-00	CERAMIC CHIP 0.1MF	25V	C504	1-106-220-00	MYLAR 0.1MF	10% 100V
C302	1-104-664-11	ELECT 47MF	20% 16V	C505	1-136-173-00	FILM 0.47MF	5% 50V
C303	1-101-004-00	CERAMIC 0.01MF	50V	C506	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C304	1-126-964-11	ELECT 10MF	20% 50V	C507	1-126-933-11	ELECT 100MF	20% 16V
C305	1-163-005-11	CERAMIC CHIP 470PF	10% 50V	C508	1-126-960-11	ELECT 1MF	20% 50V
C307	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C509	1-107-364-11	MYLAR 0.01MF	10% 200V
C308	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C510	1-163-005-11	CERAMIC CHIP 470PF	10% 50V
C309	1-126-963-11	ELECT 4.7MF	20% 50V	C513	1-107-662-11	ELECT 22MF	20% 250V
C312	1-163-099-00	CERAMIC CHIP 18PF	5% 50V	C515	1-104-666-11	ELECT 220MF	20% 25V
C313	1-163-099-00	CERAMIC CHIP 18PF	5% 50V	C517	1-104-666-11	ELECT 220MF	20% 25V
C314	1-163-038-00	CERAMIC CHIP 0.1MF	25V	C518	1-106-375-12	MYLAR 0.022MF	99% 200V
C316	1-163-259-91	CERAMIC CHIP 220PF	5% 50V	C519	1-163-275-11	CERAMIC CHIP 0.001MF	5% 50V
C317	1-136-169-00	FILM 0.22MF	5% 50V	C520	1-163-038-00	CERAMIC CHIP 0.1MF	25V
C319	1-126-964-11	ELECT 10MF	20% 50V	C531	1-126-964-11	ELECT 10MF	20% 50V
C321	1-126-963-11	ELECT 4.7MF	20% 50V	C532	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V
C322	1-164-004-11	CERAMIC CHIP 0.1MF	10% 25V	C535	1-163-251-11	CERAMIC CHIP 100PF	5% 50V
C328	1-104-664-11	ELECT 47MF	20% 25V	C536	1-107-804-11	FILM 0.68MF	5% 200V
C329	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C537	1-137-417-11	MYLAR 0.0047MF	10% 200V
C330	1-163-038-00	CERAMIC CHIP 0.1MF	25V	C538	1-165-319-11	CERAMIC CHIP 0.1MF	50V
C331	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C539	1-107-642-91	ELECT 3.3MF	20% 200V
C332	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C541	1-106-383-00	MYLAR 0.047MF	10% 200V
C333	1-126-960-11	ELECT 1MF	20% 50V	C542	1-162-116-00	CERAMIC 680PF	10% 2KV
C334	1-163-017-00	CERAMIC CHIP 0.0047MF	10% 50V	C543	1-162-134-11	CERAMIC 470PF	10% 2KV
C335	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C545	1-126-960-11	ELECT 1MF	20% 50V
C336	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C546	1-129-746-00	FILM 0.039MF	5% 400V
C337	1-164-232-11	CERAMIC CHIP 0.01MF	10% 50V	C547	1-115-522-11	FILM 1MF	5% 200V
C338	1-126-967-11	ELECT 47MF	20% 50V	C548	1-162-134-11	CERAMIC 470PF	10% 2KV
C339	1-163-038-00	CERAMIC CHIP 0.1MF	25V	C550	1-107-638-11	ELECT 33MF	20% 160V



A

The components identified by shading and marked  $\Delta$  are critical for safety  
Replace only with the part number specified.

REF. NO.	PART.NO	DESCRIPTION	REMARK	REF. NO.	PART.NO	DESCRIPTION	REMARK
D406	8-719-109-97	DIODE RD6.8ES-B2		FB608	1-412-911-11	FERRITE 00H	
D407	8-719-109-97	DIODE RD6.8ES-B2		FB609	1-410-396-41	FERRITE 0.45UH	
D408	8-719-929-15	DIODE HZS9.1NB2		FB610	1-410-397-21	FERRITE 1.1UH	
D414	8-719-109-97	DIODE RD6.8ES-B2		FB611	1-410-397-21	FERRITE 1.1UH	
D420	8-719-109-97	DIODE RD6.8ES-B2		FB612	1-535-303-00	LEAD, JUMPER (5.0MM)	
D423	8-719-109-97	DIODE RD6.8ES-B2		< IC >			
D424	8-719-929-15	DIODE HZS9.1NB2		IC001	8-759-542-54	IC SAA5491PS/M1A/088	(KV-21M5D/21M5K)
D430	8-719-109-97	DIODE RD6.8ES-B2			8-759-542-58	IC SAA5498PS/M1A/081	(KV-21T5D)
D501	8-719-908-03	DIODE GP08D			8-759-542-67	IC SAA5498PS/M1A/079	(KV-21T5K)
D502	8-719-924-13	DIODE MTZJ-T-77-22B			8-759-542-65	IC SAA5498PS/M1A/080	(KV-21T5R)
D512	8-719-908-03	DIODE GP08D		IC002	8-742-014-11	HYB IC SBX1981-51	
D513	8-719-908-03	DIODE GP08D		IC003	8-759-468-56	IC MN1381-T(TA)	
D514	8-719-908-03	DIODE GP08D		IC004	8-759-432-33	IC ST24W08FM6TR	
D534	8-719-908-03	DIODE GP08D		IC101	8-759-466-49	IC TDA9817/V1	
D536	8-719-945-80	DIODE ERC06-15S		IC201	8-759-442-73	IC TDA7494	
D539	8-719-928-08	DIODE ERD28-08S		IC301	8-752-088-38	IC CXA2060BS	
D541	1-535-303-00	LEAD, JUMPER (5.0MM)		IC501	8-759-192-71	IC STV9379	
D571	8-719-911-19	DIODE 1SS119-25		IC531	8-759-450-95	IC LM393N	
D573	8-719-921-40	DIODE MTZJ-4.7C		IC603	8-749-920-61	IC SE135N	
D601	8-719-510-53	DIODE D4SB60L		IC604	8-759-524-82	IC TYA7805CTV	
D602	8-719-046-74	DIODE AU-01Z-V1		IC605	8-759-267-25	IC LM2940T-9.0	
D603	8-719-046-74	DIODE AU-01Z-V1		IC606	8-749-014-89	IC STR-F6652	
D605	8-719-312-10	DIODE RU4AM-T3		IC608	8-759-524-82	IC TYA7805CTV	
D608	8-719-067-88	DIODE RG1CLF-B1		IC609	8-759-468-89	IC TOP209P	
D610	8-719-064-47	DIODE RN1Z		< PHOTO COUPLER >			
D613	8-719-911-19	DIODE 1SS119-25		PH601 $\Delta$	8-749-010-64	PHOTO COUPLER PC123F2	
D619	8-719-043-76	DIODE AK04VO		< SOCKET >			
D621	8-719-068-00	DIODE ERC04-06SE		J201	1-764-606-11	JACK	
D626	8-719-068-00	DIODE ERC04-06SE		J401	1-770-130-11	CONNECTOR (SQUARE TYPE) 21P	
D627	8-719-510-64	DIODE S2LA20F		J402	1-784-968-11	JACK, PIN 2P	
D628	8-719-059-23	DIODE P6KE200AG23		< COIL >			
D629	8-719-979-64	DIODE UF4005PKG23		L001	1-408-603-31	INDUCTOR 10UH	
D631	8-719-110-31	DIODE RD12ES-B2		L102	1-408-602-31	INDUCTOR 8.2UH	
D632	8-719-510-64	DIODE S2LA20F		L103	1-403-686-11	COIL	
D633	8-719-109-89	DIODE RD5.6ESB2		L104	1-535-303-00	LEAD, JUMPER (5.0MM)	
D634	8-719-064-47	DIODE RN1Z		L106	1-408-611-31	INDUCTOR 47UH	
< FUSE >				L107	1-408-605-31	INDUCTOR 15UH	
F601 $\Delta$	1-576-232-21	FUSE (H.B.C.) 5AMP 250V		L110	1-408-611-31	INDUCTOR 47UH	
$\Delta$ *1-533-725-11	HOLDER, FUSE (F601)			L202	1-408-591-11	INDUCTOR 1UH	
< FERRITE BEAD >				L203	1-406-979-11	INDUCTOR 00H	
FB001	1-412-911-11	FERRITE 00H		L204	1-408-603-31	INDUCTOR 10UH	
FB002	1-412-911-11	FERRITE 00H		L205	1-408-603-31	INDUCTOR 10UH	
FB601	1-412-911-11	FERRITE 00H		L301	1-216-295-00	SHORT 0	
FB602	1-412-911-11	FERRITE 00H					
FB605	1-410-397-21	FERRITE 1.1UH					

REF. NO.	PART.NO	DESCRIPTION	REMARK	REF. NO.	PART.NO	DESCRIPTION	REMARK
L302	1-408-611-31	INDUCTOR	47UH	< RESISTOR >			
L303	1-408-609-41	INDUCTOR	33UH	JR012	1-216-295-00	SHORT	0
L401	1-408-611-31	INDUCTOR	47UH	JR023	1-216-296-00	SHORT	0
L403	1-535-303-00	LEAD, JUMPER (5.0MM)		JR032	1-216-295-00	SHORT	0
L405	1-216-295-00	SHORT	0	JR089	1-216-295-00	SHORT	0
L501	1-408-611-31	INDUCTOR	47UH	JR090	1-216-295-00	SHORT	0
L502	1-412-531-31	INDUCTOR	33UH	JR101	1-216-295-00	SHORT	0
L503	1-412-521-31	INDUCTOR	4.7UH	JR102	1-216-295-00	SHORT	0
L532	1-412-553-11	INDUCTOR	3.3MMH	JR107	1-216-295-00	SHORT	0
L535	1-459-111-00	INDUCTOR	0UH	JR108	1-216-077-00	RES,CHIP	15K 5% 1/10W
L537	1-459-652-12	HLC		JR109	1-216-295-00	SHORT	0
L538	1-459-390-00	INDUCTOR	0UH	JR115	1-216-295-00	SHORT	0
L540	1-535-303-00	LEAD, JUMPER (5.0MM)		JR116	1-216-295-00	SHORT	0
L571	1-412-533-21	INDUCTOR	47UH	JR200	1-216-295-00	SHORT	0
L602	1-408-611-31	INDUCTOR	47UH	JR403	1-216-073-00	RES,CHIP	10K 5% 1/10W
< TRANSISTOR >				JR412	1-216-077-00	RES,CHIP	15K 5% 1/10W
Q004	8-729-216-22	TRANSISTOR	2SA1162-G	JR610	1-216-296-00	SHORT	0
Q005	1-801-806-11	TRANSISTOR	DTC144EKA	JR616	1-216-296-00	SHORT	0
Q006	1-801-806-11	TRANSISTOR	DTC144EKA	JR617	1-216-296-00	SHORT	0
Q007	8-729-620-06	TRANSISTOR	2SC3052-EF	JW220	8-719-109-89	DIODE	RD5.6ESB2
Q008	8-729-620-06	TRANSISTOR	2SC3052-EF	R001	1-216-025-00	RES,CHIP	100 5% 1/10W
Q009	8-729-620-06	TRANSISTOR	2SC3052-EF	R002	1-216-025-00	RES,CHIP	100 5% 1/10W
Q010	8-729-620-06	TRANSISTOR	2SC3052-EF	R003	1-216-065-00	RES,CHIP	4.7K 5% 1/10W
Q011	1-801-806-11	TRANSISTOR	DTC144EKA	R004	1-216-065-00	RES,CHIP	4.7K 5% 1/10W
Q012	8-729-620-06	TRANSISTOR	2SC3052-EF	R005	1-216-065-00	RES,CHIP	4.7K 5% 1/10W
Q014	8-729-620-06	TRANSISTOR	2SC3052-EF	R006	1-216-065-00	RES,CHIP	4.7K 5% 1/10W
Q101	8-729-216-22	TRANSISTOR	2SA1162-G	R007	1-216-065-00	RES,CHIP	4.7K 5% 1/10W
Q102	8-729-620-06	TRANSISTOR	2SC3052-EF	R008	1-216-025-00	RES,CHIP	100 5% 1/10W
Q103	8-729-620-06	TRANSISTOR	2SC3052-EF	R009	1-216-025-00	RES,CHIP	100 5% 1/10W
Q104	1-801-806-11	TRANSISTOR	DTC144EKA (KV-21M5K/21T5K/21T5R)	R010	1-216-025-00	RES,CHIP	100 5% 1/10W
Q105	1-801-806-11	TRANSISTOR	DTC144EKA (KV-21M5K/21T5K/21T5R)	R011	1-216-025-00	RES,CHIP	100 5% 1/10W
Q106	8-729-216-22	TRANSISTOR	2SA1162-G	R012	1-247-807-31	CARBON	100 5% 1/4W
Q202	8-729-620-06	TRANSISTOR	2SC3052-EF	R013	1-216-214-00	RES,CHIP	4.7K 5% 1/8W
Q401	8-729-216-22	TRANSISTOR	2SA1162-G	R014	1-216-057-00	RES,CHIP	2.2K 5% 1/10W
Q408	8-729-620-06	TRANSISTOR	2SC3052-EF	R015	1-216-049-00	RES,CHIP	1K 5% 1/10W
Q501	8-729-620-06	TRANSISTOR	2SC3052-EF	R017	1-249-429-11	CARBON	10K 5% 1/4W
Q532	8-729-038-83	TRANSISTOR	2SK2251-01-F19	R019	1-216-053-00	RES,CHIP	1.5K 5% 1/10W
Q533	8-729-041-25	TRANSISTOR	S2055N-16E305A	R023	1-216-295-00	SHORT	0
Q535	8-729-119-80	TRANSISTOR	2SC2688-LK	R029	1-216-073-00	RES,CHIP	10K 5% 1/10W
Q571	8-729-105-08	TRANSISTOR	2SA1330-06	R032	1-216-089-00	RES,CHIP	47K 5% 1/10W
Q574	8-729-620-06	TRANSISTOR	2SC3052-EF	R034	1-216-065-00	RES,CHIP	4.7K 5% 1/10W
Q575	1-801-806-11	TRANSISTOR	DTC144EKA	R035	1-216-049-00	RES,CHIP	1K 5% 1/10W
Q576	8-729-620-06	TRANSISTOR	2SC3052-EF	R036	1-216-065-00	RES,CHIP	4.7K 5% 1/10W
Q601	8-729-216-22	TRANSISTOR	2SA1162-G	R038	1-216-073-00	RES,CHIP	10K 5% 1/10W
				R039	1-216-089-00	RES,CHIP	47K 5% 1/10W
				R044	1-216-295-00	SHORT	0



REF. NO.	PART.NO	DESCRIPTION	REMARK			REF. NO.	PART.NO	DESCRIPTION	REMARK		
R045	1-216-295-00	SHORT	0			R102	1-216-109-00	RES,CHIP	330K	5%	1/10W
R046	1-216-085-00	RES,CHIP	33K	5%	1/10W	R104	1-216-081-00	RES,CHIP	22K	5%	1/10W
R047	1-216-067-00	RES,CHIP	5.6K	5%	1/10W	R105	1-216-081-00	RES,CHIP	22K	5%	1/10W
R048	1-216-079-00	RES,CHIP	18K	5%	1/10W	R106	1-215-900-11	METAL OXIDE	22K	5%	2W F
R049	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R107	1-216-230-00	RES,CHIP	22K	5%	1/8W
R050	1-216-041-00	RES,CHIP	470	5%	1/10W	R108	1-216-073-00	RES,CHIP	10K	5%	1/10W
R051	1-216-049-00	RES,CHIP	1K	5%	1/10W	R109	1-216-073-00	RES,CHIP	10K	5%	1/10W
R053	1-216-065-00	RES,CHIP	4.7K	5%	1/10W	R113	1-216-049-00	RES,CHIP	1K	5%	1/10W
R054	1-216-041-00	RES,CHIP	470	5%	1/10W	R114	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R055	1-216-081-00	RES,CHIP	22K	5%	1/10W				(KV-21M5K/21T5K/21T5R)		
R056	1-216-105-91	RES,CHIP	220K	5%	1/10W	R115	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R057	1-216-075-00	RES,CHIP	12K	5%	1/10W				(KV-21M5K/21T5K/21T5R)		
R058	1-216-063-91	RES,CHIP	3.9K	5%	1/10W	R117	1-216-053-00	RES,CHIP	1.5K	5%	1/10W
R059	1-216-089-00	RES,CHIP	47K	5%	1/10W	R118	1-216-295-00	SHORT	0		
R060	1-216-174-00	RES,CHIP	100	5%	1/8W	R119	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R061	1-216-174-00	RES,CHIP	100	5%	1/8W	R120	1-216-037-00	RES,CHIP	330	5%	1/10W
R062	1-216-033-00	RES,CHIP	220	5%	1/10W	R123	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R064	1-216-065-00	RES,CHIP	4.7K	5%	1/10W	R124	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
			(KV-21M5K/21T5K/21T5R)			R125	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R065	1-216-025-00	RES,CHIP	100	5%	1/10W	R131	1-216-067-00	RES,CHIP	5.6K	5%	1/10W
R066	1-216-065-00	RES,CHIP	4.7K	5%	1/10W	R132	1-216-295-00	SHORT	0		
R067	1-216-065-00	RES,CHIP	4.7K	5%	1/10W	R135	1-216-043-91	RES,CHIP	560	5%	1/10W
R068	1-216-073-00	RES,CHIP	10K	5%	1/10W				(KV-21M5K/21T5K/21T5R)		
R069	1-216-049-00	RES,CHIP	1K	5%	1/10W	R136	1-216-043-91	RES,CHIP	560	5%	1/10W
R070	1-216-081-00	RES,CHIP	22K	5%	1/10W	R142	1-216-295-00	SHORT	0		
R071	1-216-214-00	RES,CHIP	4.7K	5%	1/8W	R143	1-216-029-00	RES,CHIP	150	5%	1/10W
R072	1-216-065-00	RES,CHIP	4.7K	5%	1/10W	R144	1-216-079-00	RES,CHIP	18K	5%	1/10W
R075	1-216-069-00	RES,CHIP	6.8K	5%	1/10W	R145	1-216-212-00	RES,CHIP	3.9K	5%	1/8W
R077	1-216-083-00	RES,CHIP	27K	5%	1/10W	R150	1-216-025-00	RES,CHIP	100	5%	1/10W
R078	1-216-049-00	RES,CHIP	1K	5%	1/10W				(KV-21M5K/21T5K/21T5R)		
R079	1-216-049-00	RES,CHIP	1K	5%	1/10W	R151	1-216-049-00	RES,CHIP	1K	5%	1/10W
R080	1-216-049-00	RES,CHIP	1K	5%	1/10W	R154	1-216-238-91	RES,CHIP	47K	5%	1/8W
R081	1-216-049-00	RES,CHIP	1K	5%	1/10W	R155	1-216-089-00	RES,CHIP	47K	5%	1/10W
R082	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	R201	1-260-091-11	CARBON	220	5%	1/2W
R083	1-216-031-00	RES,CHIP	180	5%	1/10W	R204	1-247-863-91	CARBON	22K	5%	1/4W
R084	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	R205	1-260-091-11	CARBON	220	5%	1/2W
R085	1-216-031-00	RES,CHIP	180	5%	1/10W	R206	1-216-085-00	RES,CHIP	33K	5%	1/10W
R086	1-216-053-00	RES,CHIP	1.5K	5%	1/10W	R209	1-216-065-00	RES,CHIP	4.7K	5%	1/10W
R087	1-216-180-00	RES,CHIP	180	5%	1/8W	R211	1-215-873-00	METAL OXIDE	4.7K	5%	1W F
R088	1-216-065-00	RES,CHIP	4.7K	5%	1/10W	R301	1-216-025-00	RES,CHIP	100	5%	1/10W
R093	1-216-230-00	RES,CHIP	22K	5%	1/8W	R302	1-216-073-00	RES,CHIP	10K	5%	1/10W
R094	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R303	1-216-073-00	RES,CHIP	10K	5%	1/10W
R095	1-216-025-00	RES,CHIP	100	5%	1/10W	R304	1-216-073-00	RES,CHIP	10K	5%	1/10W
R096	1-247-807-31	CARBON	100	5%	1/4W	R305	1-412-002-31	INDUCTOR CHIP	4.7UH		
R097	1-247-807-31	CARBON	100	5%	1/4W	R306	1-216-206-00	RES,CHIP	2.2K	5%	1/8W
R098	1-247-807-31	CARBON	100	5%	1/4W	R309	1-216-675-11	METAL CHIP	10K	0.50%	1/10W
R101	1-216-049-00	RES,CHIP	1K	5%	1/10W	R310	1-216-022-00	RES,CHIP	75	5%	1/10W

REF. NO.	PART.NO	DESCRIPTION	REMARK			REF. NO.	PART.NO	DESCRIPTION	REMARK		
R313	1-216-025-00	RES,CHIP	100	5%	1/10W	R457	1-216-025-00	RES,CHIP	100	5%	1/10W
R314	1-216-025-00	RES,CHIP	100	5%	1/10W	R459	1-247-807-31	CARBON	100	5%	1/4W
R315	1-216-075-00	RES,CHIP	12K	5%	1/10W	R501	1-216-081-00	RES,CHIP	22K	5%	1/10W
R316	1-216-025-00	RES,CHIP	100	5%	1/10W	R502	1-216-097-00	RES,CHIP	100K	5%	1/10W
R317	1-216-049-00	RES,CHIP	1K	5%	1/10W	R503	1-215-888-00	METAL OXIDE	220	5%	2W F
R318	1-216-025-00	RES,CHIP	100	5%	1/10W	R504	1-249-385-11	CARBON	2.2	5%	1/4W F
R319	1-216-025-00	RES,CHIP	100	5%	1/10W	R505	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R320	1-216-025-00	RES,CHIP	100	5%	1/10W	R506	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R321	1-216-025-00	RES,CHIP	100	5%	1/10W	R507	1-216-349-00	METAL OXIDE	1	5%	1W F
R323	1-216-025-00	RES,CHIP	100	5%	1/10W	R508	1-216-667-11	METAL CHIP	4.7K	0.50%	1/10W
R324	1-412-002-31	INDUCTOR CHIP	4.7UH			R509	1-216-059-00	RES,CHIP	2.7K	5%	1/10W
R325	1-412-002-31	INDUCTOR CHIP	4.7UH			R510	1-216-081-00	RES,CHIP	22K	5%	1/10W
R326	1-216-129-00	RES,CHIP	2.2M	5%	1/10W	R512	1-249-382-11	CARBON	1.2	5%	1/4W F
R331	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R514	1-249-377-11	CARBON	0.47	5%	1/4W F
R332	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R515	1-249-377-11	CARBON	0.47	5%	1/4W F
R333	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	R516	1-249-493-11	CARBON	56K	5%	1/2W
R334	1-216-025-00	RES,CHIP	100	5%	1/10W	R517	1-249-436-11	CARBON	39K	5%	1/4W
R335	1-216-025-00	RES,CHIP	100	5%	1/10W	R518	1-216-065-00	RES,CHIP	4.7K	5%	1/10W
R338	1-216-049-00	RES,CHIP	1K	5%	1/10W	R519	1-216-121-91	RES,CHIP	1M	5%	1/10W
R401	1-216-113-00	RES,CHIP	470K	5%	1/10W	R520	1-215-883-11	METAL OXIDE	33	5%	2W F
R402	1-216-077-00	RES,CHIP	15K	5%	1/10W	R522	1-216-097-00	RES,CHIP	100K	5%	1/10W
R403	1-216-041-00	RES,CHIP	470	5%	1/10W	R523	1-216-117-00	RES,CHIP	680K	5%	1/10W
R404	1-216-113-00	RES,CHIP	470K	5%	1/10W	R524	1-216-085-00	RES,CHIP	33K	5%	1/10W
R405	1-216-295-00	SHORT	0			R525	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R406	1-216-113-00	RES,CHIP	470K	5%	1/10W	R526	1-216-089-00	RES,CHIP	47K	5%	1/10W
R408	1-216-022-00	RES,CHIP	75	5%	1/10W	R527	1-216-075-00	RES,CHIP	12K	5%	1/10W
R409	1-216-025-00	RES,CHIP	100	5%	1/10W	R528	1-216-246-00	RES,CHIP	100K	5%	1/8W
R410	1-216-025-00	RES,CHIP	100	5%	1/10W	R529	1-216-073-00	RES,CHIP	10K	5%	1/10W
R411	1-216-022-00	RES,CHIP	75	5%	1/10W	R530	1-216-085-00	RES,CHIP	33K	5%	1/10W
R412	1-216-025-00	RES,CHIP	100	5%	1/10W	R531	1-216-057-00	RES,CHIP	2.2K	5%	1/10W
R413	1-216-295-00	SHORT	0			R532	1-216-065-00	RES,CHIP	4.7K	5%	1/10W
R414	1-216-022-00	RES,CHIP	75	5%	1/10W	R533	1-216-081-00	RES,CHIP	22K	5%	1/10W
R415	1-216-022-00	RES,CHIP	75	5%	1/10W	R539	1-216-049-00	RES,CHIP	1K	5%	1/10W
R417	1-247-804-11	CARBON	75	5%	1/4W	R540	1-215-887-00	METAL OXIDE	150	5%	2W F
R418	1-249-413-11	CARBON	470	5%	1/4W	R541	1-216-105-91	RES,CHIP	220K	5%	1/10W
R419	1-216-022-00	RES,CHIP	75	5%	1/10W	R542	1-216-089-00	RES,CHIP	47K	5%	1/10W
R420	1-216-041-00	RES,CHIP	470	5%	1/10W	R543	1-216-089-00	RES,CHIP	47K	5%	1/10W
R421	1-216-113-00	RES,CHIP	470K	5%	1/10W	R545	1-216-129-91	RES,CHIP	2.2M	5%	1/8W
R422	1-216-295-00	SHORT	0			R546	1-249-401-11	CARBON	47	5%	1/4W F
R425	1-216-077-00	RES,CHIP	15K	5%	1/10W	R547	1-535-143-71	LEAD, JUMPER (7.5MM)			
R426	1-216-073-00	RES,CHIP	10K	5%	1/10W	R548	1-212-849-00	FUSIBLE	4.7	5%	1/4W F
R445	1-216-171-00	RES,CHIP	75	5%	1/8W	R549	1-216-371-00	METAL OXIDE	1.5	5%	2W F
R446	1-216-113-00	RES,CHIP	470K	5%	1/10W	R551	1-215-873-00	METAL OXIDE	4.7K	5%	1W F
R447	1-216-077-00	RES,CHIP	15K	5%	1/10W	R552	1-216-061-00	RES,CHIP	3.3K	5%	1/10W
R450	1-216-041-00	RES,CHIP	470	5%	1/10W	R553	1-249-381-11	CARBON	1	5%	1/4W F
R454	1-216-041-00	RES,CHIP	470	5%	1/10W	R554	1-216-109-91	RES,CHIP	330K	5%	1/8W
R455	1-216-295-00	SHORT	0			R571	1-249-417-11	CARBON	1K	5%	1/4W F



The components identified by shading and marked  $\Delta$  are critical for safety  
Replace only with the part number specified.

REF. NO.	PART.NO	DESCRIPTION	REMARK			
R572	1-216-369-00	METAL OXIDE	1	5%	2W	F
R573	1-216-101-00	RES,CHIP	150K	5%	1/10W	
R574	1-216-065-00	RES,CHIP	4.7K	5%	1/10W	
R575	1-216-097-00	RES,CHIP	100K	5%	1/10W	
R581	1-216-089-00	RES,CHIP	47K	5%	1/10W	
R582	1-216-089-00	RES,CHIP	47K	5%	1/10W	
R583	1-216-081-00	RES,CHIP	22K	5%	1/10W	
R588	1-216-051-00	RES,CHIP	1.2K	5%	1/10W	
R589	1-216-097-00	RES,CHIP	100K	5%	1/10W	
R590	1-216-073-00	RES,CHIP	10K	5%	1/10W	
R591	1-215-892-11	METAL OXIDE	1K	5%	2W	F
R593	1-249-439-11	CARBON	68K	5%	1/4W	
R594	1-216-057-00	RES,CHIP	2.2K	5%	1/10W	
R595	1-249-377-11	CARBON	0.47	5%	1/4W	F
R602	1-202-961-11	CEMENTED	1.8	5%	10W	
R603	1-202-933-61	FUSIBLE	0.1	10%	1/2W	F
R607	△ 1-202-961-11	CEMENTED	1.8	5%	10W	
R608	1-215-927-00	METAL OXIDE	47K	5%	3W	F
R611	1-249-415-11	CARBON	680	5%	1/4W	
R613	△ 1-240-030-91	METAL	4.7M	5%	1/2W	
R614	△ 1-240-030-91	METAL	4.7M	5%	1/2W	
R615	1-249-420-11	CARBON	1.8K	5%	1/4W	
R616	1-216-397-11	METAL OXIDE	4.7	5%	3W	F
R617	1-249-405-11	CARBON	100	5%	1/4W	F
R619	1-216-065-00	RES,CHIP	4.7K	5%	1/10W	
R622	1-249-393-11	CARBON	10	5%	1/4W	
R627	1-249-385-11	CARBON	2.2	5%	1/4W	F
R628	1-247-791-91	CARBON	22	5%	1/4W	
R652	1-216-397-11	METAL OXIDE	4.7	5%	3W	F
R653	1-216-397-11	METAL OXIDE	4.7	5%	3W	F
R658	1-215-929-11	METAL OXIDE	100K	5%	3W	F
R659	1-216-382-21	METAL OXIDE	0.27	5%	3W	F
R661	1-247-843-11	CARBON	3.3K	5%	1/4W	
R662	1-215-929-11	METAL OXIDE	100K	5%	3W	F
R664	1-249-417-11	CARBON	1K	5%	1/4W	
R665	1-215-877-11	METAL OXIDE	22K	5%	1W	F
R667	1-215-927-00	METAL OXIDE	47K	5%	3W	F
< RELAY >						
RY601	△ 1-755-245-11	RELAY, AC POWER				
< SWITCH >						
S001	1-571-532-21	SWITCH, TACTIL				
S002	1-571-532-21	SWITCH, TACTIL				
S003	1-571-532-21	SWITCH, TACTIL				
S004	1-571-532-21	SWITCH, TACTIL				
S005	1-571-532-21	SWITCH, TACTIL				

REF.NO.	PART.NO	DESCRIPTION	REMARK		
S006	1-571-532-21	SWITCH, TACTIL			
S601	△ 1-571-433-21	SWITCH, PUSH (AC POWER)			
< TRANSFORMER >					
T511	△ 1-453-279-11	TRANSFORMER ASSY, FLYBACK (NX-1747/U2B)			
T531	1-437-195-11	TRANSFORMER, HORIZONTAL DRIVE			
T601	△ 1-433-411-11	TRANSFORMER, LINE FILTER			
T602	1-431-732-11	TRANSFORMER, CONVERTER (SRT)			
T603	△ 1-433-424-11	TRANSFORMER, CONVERTER			
< THERMISTOR >					
THP601	△ 1-808-059-31	THERMISTOR, POSITIVE			
< TUNER >					
TU101	8-598-331-02	TUNER, VSS BT-AC401			
< CRYSTAL >					
X001	1-578-774-11	VIBRATOR, CRYSTAL			
X302	1-567-505-11	OSCILLATOR, CRYSTAL			
X303	1-567-504-11	OSCILLATOR, CRYSTAL			
*****					
*A-1638-115-A C BOARD, COMPLETE					
*****					
< CAPACITOR >					
C701	1-102-114-00	CERAMIC	470PF	10%	50V
C702	1-102-109-91	CERAMIC	180PF	10%	50V
C703	1-102-109-91	CERAMIC	180PF	10%	50V
C708	1-162-114-00	CERAMIC	0.0047MF		2KV
C710	1-136-189-00	FILM	0.1MF	10%	250V
C712	1-102-109-91	CERAMIC	180PF	10%	50V
C714	1-104-664-11	ELECT	47MF	20%	16V
C717	1-102-114-00	CERAMIC	470PF	10%	50V
C718	1-102-114-00	CERAMIC	470PF	10%	50V
C719	1-102-114-00	CERAMIC	470PF	10%	50V
< CONNECTOR >					
CN702	1-695-915-11	TAB (CONTACT)			
CN703	*1-564-509-11	PLUG, CONNECTOR 6P			
CN705	1-695-915-11	TAB (CONTACT)			
CN706	1-695-915-11	TAB (CONTACT)			
CN707	*1-564-508-11	PLUG, CONNECTOR 5P			
< DIODE >					
D701	8-719-109-89	DIODE RD5.6ESB2			
D702	8-719-991-33	DIODE 1SS133T-77			

The components identified by shading and marked  $\Delta$  are critical for safety  
Replace only with the part number specified.

C

REF. NO.	PART.NO	DESCRIPTION	REMARK	REF. NO.	PART.NO	DESCRIPTION	REMARK
D703	8-719-991-33	DIODE 1SS133T-77		R712	1-260-099-11	CARBON 1K 5%	1/2W
D704	8-719-991-33	DIODE 1SS133T-77		R713	1-249-439-11	CARBON 68K 5%	1/4W
D705	8-719-991-33	DIODE 1SS133T-77		R714	1-215-899-11	METAL OXIDE 15K 5%	2W F
D706	8-719-991-33	DIODE 1SS133T-77		R715	1-535-143-11	LEAD, JUMPER (10.0MM)	
D707	8-719-991-33	DIODE 1SS133T-77		R716	1-247-815-91	CARBON 220 5%	1/4W
D708	1-535-303-00	LEAD, JUMPER (5.0MM)		R717	1-249-411-11	CARBON 330 5%	1/4W
D709	8-719-991-33	DIODE 1SS133T-77		R718	1-202-814-11	SOLID 33K 10%	1/2W
D710	8-719-991-33	DIODE 1SS133T-77		R719	1-249-408-11	CARBON 180 5%	1/4W
D711	1-216-349-00	METAL OXIDE 1 5%	1W F	R720	1-249-427-11	CARBON 6.8K 5%	1/4W
D712	8-719-991-33	DIODE 1SS133T-77		R721	1-535-143-61	LEAD, JUMPER (5.0MM)	
D713	1-535-303-00	LEAD, JUMPER (5.0MM)		R722	1-202-848-00	SOLID 680K 10%	1/2W
D714	8-719-991-33	DIODE 1SS133T-77		R723	1-535-143-11	LEAD, JUMPER (10.0MM)	
D715	1-535-303-00	LEAD, JUMPER (5.0MM)		R726	1-260-099-11	CARBON 1K 5%	1/2W
D716	8-719-991-33	DIODE 1SS133T-77		R727	1-247-815-91	CARBON 220 5%	1/4W
D718	8-719-991-33	DIODE 1SS133T-77		R728	1-216-351-00	METAL OXIDE 1.5 5%	1W F
D719	1-535-303-00	LEAD, JUMPER (5.0MM)		R729	1-249-411-11	CARBON 330 5%	1/4W
< CRT SOCKET >				R730	1-249-408-11	CARBON 180 5%	1/4W
J701 $\Delta$	1-251-595-11	SOCKET, CRT		R731	1-249-427-11	CARBON 6.8K 5%	1/4W
< COIL >				R734	1-247-807-31	CARBON 100 5%	1/4W
L704	1-414-186-31	INDUCTOR 33UH		R736	1-215-899-11	METAL OXIDE 15K 5%	2W F
< TRANSISTOR >				R737	1-247-891-00	CARBON 330K 5%	1/4W
Q701	8-729-046-28	TRANSISTOR BF420-126		R739	1-535-143-11	LEAD, JUMPER (10.0MM)	
Q702	8-729-119-78	TRANSISTOR 2SC2785-HFE		R741	1-202-549-00	SOLID 100 20%	1/2W
Q703	8-729-046-28	TRANSISTOR BF420-126		R743	1-535-143-61	LEAD, JUMPER (5.0MM)	
Q704	8-729-200-17	TRANSISTOR 2SA1091-O		R746	1-249-417-11	CARBON 1K 5%	1/4W
Q705	8-729-119-78	TRANSISTOR 2SC2785-HFE		R750	1-249-417-11	CARBON 1K 5%	1/4W
Q706	8-729-046-28	TRANSISTOR BF420-126		R751	1-249-417-11	CARBON 1K 5%	1/4W
Q707	8-729-200-17	TRANSISTOR 2SA1091-O		< VARIABLE RESISTOR >			
Q708	8-729-119-78	TRANSISTOR 2SC2785-HFE		RV702	1-241-656-21	RES, ADJ, METAL FILM 110M	
Q709	8-729-046-28	TRANSISTOR BF420-126					
Q710	8-729-200-17	TRANSISTOR 2SA1091-O					
Q712	8-729-046-28	TRANSISTOR BF420-126					
Q713	8-729-046-28	TRANSISTOR BF420-126					
< RESISTOR >							
R701	1-247-895-91	CARBON 470K 5%	1/4W				
R702	1-215-899-11	METAL OXIDE 15K 5%	2W F				
R703	1-535-143-61	LEAD, JUMPER (5.0MM)					
R705	1-260-099-11	CARBON 1K 5%	1/2W				
R706	1-247-815-91	CARBON 220 5%	1/4W				
R707	1-249-411-11	CARBON 330 5%	1/4W				
R708	1-249-408-11	CARBON 180 5%	1/4W				
R711	1-249-427-11	CARBON 6.8K 5%	1/4W				



The components identified by shading and marked **△** are critical for safety  
Replace only with the part number specified.

REF.NO.	PART.NO	DESCRIPTION	REMARK	REF.NO.	PART.NO	DESCRIPTION	REMARK
<b>MISCELLANEOUS</b> *****				<b>ACCESSORIES AND PACKAGING MATERIAL</b> *****			
△	1-416-329-11	COIL, DEMAGNETIC		4-204-422-11	MANUAL, INSTRUCTIONS (KV-21M5D/21T5D)		
	1-452-032-00	MAGNET, DISC; 10MM Ø			(ENGLISH/GREEK/TURKISH)		
	1-452-094-00	MAGNET, ROTATABLE DISC; 15MM Ø		4-204-422-91	MANUAL, INSTRUCTIONS (KV-21M5K/21T5K/21T5R)		
△	1-453-279-11	TRANSFORMER ASSY, FLYBACK (NX-1747/U2B)			(ENGLISH/CZECH/POLISH/RUSSIAN/HUNGARIAN/BULGARIAN)		
	1-598-128-11	SPEAKER					
△	1-540-006-22	CAP ASSY, HIGH-VOLTAGE		4-039-905-02	BAG, PROTECTION		
△	1-571-433-21	SWITCH, PUSH (AC POWER)		4-204-357-01	INDIVIDUAL CARTON		
△	1-590-501-21	CORD POWER (WITH NOISE FILTER)		4-204-355-01	CUSHION (LOWER) (ASSY)		
	8-598-331-02	TUNER (VSS BT-AC401)		4-204-351-01	CUSHION (UPPER) (ASSY)		
△	8-451-295-45	DEFLECTION YOKE (Y21PFA2BA)					
				*****			
△	8-738-784-05	PICTURE TUBE (SD-169) (A51JXH61X)			REMOTE COMMANDER		
△	7-738-784-72	ITC			*****		
*****							
				1-475-765-21	COMMANDER, STANDARD TYPE (RM-883)		